

# PLAYTIME

## BASICSHOPPER



19 31 -- 7 25 96

19 48 -- 7 25 96

### BASICShopper

	Cod.	mm	Um	Pz	Box
SMALL	19 -- 16 7 25 96	160 x 70 x 215	PA	25	18
MEDIUM	19 -- 24 7 25 96	240 x 100 x 310	PA	25	10
LARGE	19 -- 36 7 25 96	360 x 120 x 410	PA	25	8

# TRAVEL

## BASICSHOPPER



70

### BASICShopper

	Cod.	mm	Um	Pz	Box
SMALL	19 45 16 7 25 70	160 x 70 x 215	PA	25	18
MEDIUM	19 45 24 7 25 70	240 x 100 x 310	PA	25	10
LARGE	19 45 36 7 25 70	360 x 120 x 410	PA	25	8